















NOTES:

- 1. REFER TO STD DWG SL 12 FOR LOOP DETECTOR DETAILS.
- 2. MAINTAIN 12" MIN. SPACING BETWEEN SAW CUT, AND ANY CONCRETE JOINTS.
- 3. USE FLEXIBLE MATERIAL CROSSING JOINTS.
- 4. GRIND FLUSH WITH SURFACE AFTER CURED.



AT 14